



ATI Radeon Graphics Card Cable Replacement Instructions


First Steps


Note: Follow these instructions carefully. Failure to do so could damage your equipment and void its warranty.

- 1 Shut down computer.
- 2 Wait 10 minutes.
 **Warning:** Parts inside computer can be very hot. Allow computer to cool down before continuing.
- 3 Unplug all external cables except power cord.
- 4 Touch metal PCI cover on back of computer.
- 5 Unplug power cord.




Opening the Computer

- 1 Hold side access panel and lift latch on back of computer.
 **Warning:** Edges of access panel and enclosure can be sharp. Be careful when handling.
- 2 Remove access panel and place it on flat surface covered by soft, clean cloth.



Removing and Installing the Cable

- 1 Disconnect card's cable(s) from backplane board.
- 2 Disconnect card's cable(s) from card.
- 3 Connect replacement cable(s) to card and backplane board.



Closing the Computer

- 1 Replace access panel.
Note: Make sure latch is up before you replace panel. If latch is down, panel will not seat correctly.
- 2 Push latch down to close and secure access panel.



Warning: Never turn on computer unless all its internal and external parts are in place and it is closed. Operating computer when open or missing parts can cause damage or injury.

