

Memory, SO-DIMM Installation Instructions

Follow the instructions in this sheet carefully. Failure to follow these instructions could damage your equipment and void its warranty.

Note: This computer uses double-data rate (DDR) memory. Memory from previous iMac models is not compatible with this computer. Do not use older SO-DIMMs even if they fit into the slot. Memory used in this slot should be low-profile PC2100 (DDR266) SO-DIMM for the 17-inch 1 GHz and PC2700 (DDR333) for the iMac (USB 2.0) models.

Written and video instructions covering customer-installable parts are available at <http://www.info.apple.com/installparts/>.

Tools Required

- #1 Phillips screwdriver
- Soft cloth

Opening the Computer

Warning: Always shut down your computer before opening it to avoid damaging its internal components or causing injury.


1. Unplug all cables from the computer except the power cord.
2. Supporting the neck and the base, lay the computer down on a soft cloth as shown in Figure 1.

Figure 1



3. Loosen the four captive screws at the base of the computer and gently remove the access panel (Figure 2).

Figure 2



Important: To avoid electrostatic discharge, always ground yourself by touching metal before you touch any parts or install any components inside the computer. To avoid static electricity building back up in your body, do not walk around the room until you have completed the installation and closed the computer.

4. Touch a metal surface inside the computer (Figure 3).

Figure 3



-
5. **Warning:** Do not remove the screws on the bottom housing (Figure 4). Loosening these screws could cause the computer to overheat and damage internal components.

Figure 4



6. Unplug the power cord.


Installing the Memory Module

This computer uses double-data rate (DDR) memory. Memory from previous iMac models is not compatible with this computer.

Note: If you are replacing defective memory, rather than adding memory, remove the defective card before proceeding.

1. Insert the memory module into the expansion slot (Figure 5).

Figure 5



2. Make sure the memory card is fully inserted into the slot. Check that the notches in the card clear the tabs as you press down on the sides of the card to lock it into place. Press down gently on the memory until you hear it click into place under the two locking tabs on the sides of the slot (Figure 6).

Figure 6



Closing the Computer

1. Replace the access panel and tighten the four captive screws (Figure 7).

Figure 7



2. Reconnect all cables and restart the computer.

Warning: Never turn on the computer unless all of its internal and external parts are in place and it is closed. Operating the computer when it is open or missing parts can damage your computer or cause injury.

🍏 Apple Computer, Inc.

© 2003 Apple Computer, Inc. All rights reserved.

Under the copyright laws, this document may not be copied, in whole or in part, without the written consent of Apple.

The Apple logo is a trademark of Apple Computer, Inc., registered in the U.S. and other countries. Use of the “keyboard” Apple logo (Option-Shift-K) for commercial purposes without the prior written consent of Apple may constitute trademark infringement and unfair competition in violation of federal and state laws.

Every effort has been made to ensure that the information in this document is accurate. Apple is not responsible for printing or clerical errors.

Apple Computer, Inc.
1 Infinite Loop
Cupertino, CA 95014-2084
USA
+ 1 408 996 1010
<http://www.apple.com>

Apple, the Apple logo, Mac, Macintosh, and the Mac logo are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

iMac is a trademark of Apple Computer, Inc.